CARVER MOBILE RANCH and the Received (1)

Mar 26 2022 **Cross Connection**

damage to the system or its appurtenances.

CROSS CONNECTION REGULATION

Pursuant to Chapter 333, Division 61 of the Oregon Administrative Rules, it is the responsibility of the CARVER MOBILE RANCH to protect its drinking water by instituting and enforcing a cross connection program. Therefore, the following regulation is hereby adopted:

Contents:

(10) "Plumbing hazard" means an internal or plumbing-type cross-connectantinifed 10:1

1:02 Purpose mater system than may be either a pollutional or a contampsoque?

1:05 Installation Requirements wash trays, domestic washing machines and lawn sprinkling syste

1:06 Access to Premises

1:07 Annual Testing and Repairs

1:08 Costs of Compliance

1:09 Termination of Service the edital to potential or potential or potential or "Pollutional Research and Pollutional Original O the water system or the potability of the public or the consumer's putab

1:10 Effective Date which would not constitute a health or system bazard, as defined. The maximum degree of

definition would cause a puisance or he aesthetically objectionable or could ca ZNOITINITED 10:1

- (1) "Approved backflow prevention assembly" means an assembly to counteract backpressure or prevent backsiphonage. This assembly must appear on the list of approved assemblies issued by the Oregon Health Division.
- (2) "Auxiliary supply" means any water source or system other than the public water system, that may be available in the building or on the premises.
- (3) "Backflow" means the flow in the direction opposite to the normal flow or the introduction of any foreign liquids, gases, or substances into the water system of the Water Company's water.
- (4) "Contamination" means the entry into or presence in a public water supply system of any substance which may be deleterious to health and/or quality of the water.
- (5) "Cross Connection" means any physical arrangement where a public water system is connected, directly or indirectly, with any other non-drinkable water system or auxiliary system, sewer, drain conduit, swimming pool, storage reservoir, plumbing fixture, swamp coolers, or any other device which contains. or may contain, contaminated water, sewage, or other liquid of unknown or unsafe quality which may be capable of imparting contamination to the public water system as a result of backflow. Bypass arrangements, jumper connections, removable sections, swivel or change over devices, or other temporary or permanent devices through which, or because of which, backflow may occur are considered to be cross connections.

- (6) "Degree of hazard" shall be derived from the evaluation of a health, system, plumbing or pollutional hazard.
- (7) "Director" means the supertendant of the Co-Op or other authorized agent.
- (8) "Co-Op" means the CARVER MOBILE RANCH.
- (9) "Health hazard" means an actual or potential threat of contamination of a physical or toxic nature to the public potable water system or the consumer's potable water system that would be a danger to health.
- (10) "Plumbing hazard" means an internal or plumbing-type cross-connection in a consumer's potable water system than may be either a pollutional or a contamination-type hazard. This Includes, but is not limited to, cross connections to toilets, sinks, lavatories, wash trays, domestic washing machines and lawn sprinkling systems. Plumbing-type cross connections can be located in many types of structures including homes, apartment houses, hotels and commercial or industrial establishments.
- (11) "Pollutional hazard" means an actual or potential threat to the physical properties of the water system or the potability of the public or the consumer's potable water system but which would not constitute a health or system hazard, as defined. The maximum degree of intensity of pollution to which the potable water system could be degraded under this definition would cause a nuisance or he aesthetically objectionable or could cause minor damage to the system or its appurtenances.
- (12) "System hazard" means an actual or potential threat of severe danger to the physical properties of the public or consumer's potable water system or of a pollution or contamination which would have a detrimental effect on the quality of the potable water in the system.
- (13) "Potable water supply" means any system of water supply intended or used for human consumption or other domestic us.
- (14) "Premises" means any piece of land to which water is provided including all improvements, mobile home(s) and structures located on it.
- (13) "Reduced pressure principle assembly" shall mean an assembly containing two, independently acting, approved check valves together with a hydraulically operated, mechanically independent, pressure differential relief valve located between the check valves and at the same time below the first check valve, The assembly shall include properly located test cocks and tightly closing shut-off valves at the end of the assembly, A check valve is approved if it appears on the list of approved assemblies issued by the Oregon Health Division,

- (14) "Premises" means any piece of land to which water is provided including all to started (0) improvements, mobile home(s) and structures located on it.
- (13) "Reduced pressure principle assembly" shall mean an assembly containing two, independently acting, approved check valves together with a hydraulically operated, mechanically independent, pressure differential relief valve located between the check valves and at the same time below the first check valve, The assembly shall include properly located test cocks and tightly closing shut-off valves at the end of the assembly, A check valve is approved if it appears on the list of approved assemblies issued by the Oregon Health Division,

1:02 PURPOSE out of before a serial and a serial property of the sprinkler system as a serial serial

The purpose of this Regulation is to protect the water supply of the CARVER MOBILE RANCH from contamination or pollution due to any existing or potential cross connections,

install an approved backflow prevention assembly or the property owner shall assume all

1:03 CROSS CONNECTIONS REGULATED

No cross connections shall be created, installed, used or maintained within the territory served by the CARVER MOBILE RANCH, except in accordance with this Regulation.

1:04 BACKFLOW PREVENTION ASSEMBLY REQUIREMENTS

Approved backflow prevention assemblies shall be installed at the expense of the user, either at the service connection or within the premises, as determined by a certified cross connection inspector employed by the CARVER MOBILE RANCH, whenever:

- (1) The nature and extent of any activity of the premises, or the materials used in all out at demand connection with any activity of the premises, or materials stored on the premises, could are another contaminate or pollute the drinking water supply.
- (2) Premises having any one or more cross connections as that term is defined in Section 1:01 Paragraph 5 are identified or are present.
- (3) Internal cross connections that are not correctable, or intricate plumbing arrangements which make it impractical to ascertain whether or not cross connections exist are present.
- (4) There is a repeated history of cross connections being established or reestablished.
- (5) There is unduly restricted entry so that inspections for cross connections cannot be made with sufficient frequency or with sufficient notice to assure that cross connections do not exist.

- (6) Materials of a toxic or hazardous nature are being used such that, if backflow should occur, a health hazard could result.
- (7) Any mobile apparatus which uses Coop water or water from any premises within the Coop system.
- (8) Installation of an approved backtlow prevention assembly is deemed to be necessary to accomplish the purpose of these regulations in the judgment of a certified cross connection specialist employed by the CARVER MOBILE RANCH.
- (9) An appropriate cross connection report form has not been filed with the Coop.
- (10) A fire sprinkler system using non-potable piping material is connected to the Coop's water system.
- (11) All residential properties occupied by persons other than the property owner shall install an approved backflow prevention assembly or the property owner shall assume all responsibility for any backflow that should occur.

1:05 INSTALLATION REQUIREMENTS

To ensure proper operation and accessibility of all backflow prevention assemblies, the following requirements shall apply to the installation of these assemblies.

- (1) No part of the backflow prevention assembly shall be submerged in water or installed in a location subject to flooding. If installed in a vault or basement, adequate drainage shall be provided.
- (2) Assemblies must be installed at the point of delivery of the water supply, before any branch in the line, on private property located just inside of the property line. Alternate locations must be approved in writing by the Coop prior to installations.
- (3) The assembly must be protected from freezing and other severe weather conditions.
- (4) All backflow prevention assemblies shall be of a type and model approved by the Oregon Health Division and the Coop.
- (5) Only assemblies specifically approved by the Oregon Health Division for vertical installation may be installed vertically.
- (6) The assembly shall be readily accessible with adequate room for maintenance and testing. Assemblies 2 inches and smaller shall have at least 6 inch clearance on all sides of the assembly. All assemblies larger than 2 inches shall have a minimum clearance of 12 inches on the back side, 24 inches on the test cock side, 12 inches below the assembly and 36

inches above the assembly. "Y" pattern double check valve assemblies shall be installed so what the the checks are horizontal and the test cocks face upward.

- (7) The property owner assumes all responsibility for all maintenance and testing of the assembly, as determined and required by the Coop.
- (8) If written permission is granted to install the backtlow assembly inside of the building, the assembly shall be readily accessible during regular working hours of 8:00 a.m. to 5:00 p.m., Monday through Friday.
- (9) If an assembly, with written permission, is installed inside of the premises and is 4 1000 80 inches or larger and is installed 4 feet above the floor, it must be equipped with a rigidly and permanently installed scaffolding acceptable to the Coop. This installation must also meet the requirements set out by the U.S. Occupational Safety and Health Administration and the State of Oregon Occupational Safety and Health Codes.
- (10) Reduced pressure principle assemblies may be installed in a vault only if relief valve discharge can be drained to daylight through a "boresight" type drain. The drain shall be of adequate capacity to carry the full rated flow of the assembly and shall be screened on both ends.
- (11) An approved air gap shall be located at the relief valve orifice. This air gap shall be at least twice the inside diameter of the incoming supply line as measured vertically above the top rim of the drain and in no case less than 1 inch.
- (12) Upon completion of installation, the Coop shall be notified and all assemblies must be inspected and tested. All backflow prevention assemblies must be registered with the Coop. Registration shall consist of date of installation, make model, serial number of the backflow assembly, and initial test report.
- (13) Any water pressure drop caused by the installation of a backflow assembly is not the responsibility of the Coop.
- (14) New construction may be required to install an approved backflow assembly at the service connection if deemed necessary by Coop's superntendant.

1:06 ACCESS TO PREMISES

Authorized representatives of the Coop, with proper identification, shall have access during reasonable hours to all parts of a premise and within the building to which water is supplied. However, if any water user refuses access to a premise or to the interior of a structure at reasonable times and on reasonable notice for inspection by a cross connection specialist appointed by the Coop, a reduced pressure principle assembly will be required to be installed at the service connection to that premise.

Cross Connection Regulation

1:07 ANNUAL TESTING AND REPAIRS

All backflow assemblies installed within the territory served by the Coop shall be tested immediately upon installation and at least annually thereafter by a state-certified tester. All such assemblies found not functioning properly shall he promptly repaired or replaced by the water user. If any such assembly is not promptly repaired or replaced, the Coop may deny or discontinue water to the premise. All testing and repairs are the financial responsibility or the water user.

1:08 COSTS OF COMPLIANCE

All costs associated with purchase installation, inspections testing, replacement maintenance, parts, and repairs of the backflow assembly are the financial responsibility of the property owner.

1:09 TERMINATION OF SERVICE

Failure on the part of any customer to discontinue the use of all cross connections and to physically separate cross connections is sufficient cause for the immediate discontinuance of water service to the premises (OAR Chapter 333-061-070, Section 1).

1:10 EFFECTIVE DATE

This Regulation shall be effective as of March 23, 2022.

CARVER MOBILE RANCH